

ACCEPTABLE TRANSOM APPLICATIONS FOR HERITAGE FLUSH WOOD DOORS

MEETING RAILS	20-MINUTE NEUTRAL	20-MINUTE POSITIVE	45-MINUTE NEUTRAL	45-MINUTE POSITIVE	60-MINUTE NEUTRAL	60-MINUTE POSITIVE	90-MINUTE NEUTRAL	90-MINUTE POSITIVE
Square with No Transom Bar	1, 5, 6	N/A	1, 4, 5, 11	N/A	1, 4, 5, 11	N/A	1, 4, 5, 11	N/A
Square with Transom Bar	5, 6	5, 7, 10	2, 5, 7, 10	8, 9, 10	2, 5, 7, 10	8, 9, 10	2, 5, 7, 10	8, 9, 10
Rabbetted	3, 4, 5, 11	N/A	2, 4, 5, 11	N/A	2, 4, 5, 11	N/A	2, 4, 5, 11	N/A

1. Door Transom Astragal (DTA) required
2. Metal meeting edge & astragal required.
3. 5-Ply Door required.
4. 5" Firestop™ meeting rails required.
5. Maximum single opening size 4-0 x 10-0; maximum transom size 4-0 x 3-4.
6. Maximum paired opening size 8-0 x 10-0; maximum transom size 8-0 x 3-4.
7. Maximum paired opening size 8-0 x 10-0; maximum transom size 4-0 x 3-4
8. Maximum paired opening size 8-0 x 9-0; maximum transom size 4-0 x 3-4
9. Maximum single opening size 4-0 x 9-0; maximum transom size 4-0 x 3-4
10. Transoms over a pair must be separated by a fixed mullion, limiting the width of each panel to the width of each leaf of the pair.
11. Single swing only - no pairs

Maximum sizes noted dependent upon hardware.

On coordinated orders, state whether bottom of transom must be wood taped.